




Communication failure

Aircraft with Communication failure is not allow to enter Arlanda CTR.

In case of Communication failure proceed to aerodrome outside Arlanda CTR.

Remark

Note: Noise sensitive area should be avoided below 2000 ft AMSL

Legend

See GEN 2.3

RWY NR	THR ELEV	PAPI (MEHT)
01L	98.1 ft	Left/3.00° (61 ft)
19R	117.6 ft	Left/3.00° (56 ft)
01R	137.4 ft	Right/3.00° (57 ft)
19L	98.4 ft	Left/3.00° (57 ft)
08	108 ft	Left/3.00° (56 ft)
26	124.3 ft	Left/3.00° (60 ft)

Entry / exit point

SKEDVIKEN	594614N 0181526E
VADA	593525N 0181248E
VASSUNDA	594223N 0174438E

Holding

ODENSALA: Hold at Odensala Church, west of point 593948N 0175054E

MARKIM: Hold at Markim Church, east of point 593630N 0180359E